

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
888	178									
A.R. Systems	004	081								
ACE	207									
Acme	052	179								
Acura	037	273								
ADA	183									
ADC	100	178								
Admiral	009	085	115	177	178	187	191	297		
Adyson	061	179								
Agashi	061									
Agazi	178									
AGB	200									
Aiko	004	006	037	061	100	179				
Aim	004									
Aiwa	004	010	051							
Akai	004	006	015	031	037	046	059	061	077	100
	105	106	107	108	109	110	111	114	183	187
	191	193	200	265	282	314	321	324	328	329
Akiba	004	015	069	086						
Akito	189	300								
Akura	004	015	037	069	111	178	269	321		
Alaron	061									
Alba	004	015	031	037	055	061	064	066	085	092
	093	179	194	211	258	267	313	318		
ALBIRAL	260									
Alcyon	043									
Alkos	006									
Allorgan	061	073	084							
Allstar	004	059								
AMOi	168									
Amplivision	061	074	083	179	211					
Amstrad	004	015	031	037	039	050	057	178	190	193
	199	200	269	273	297	321				
Anam	005	037	298							
Anglo	037									
Anhua	243									
Anitech	004	037	043	178	298					
Ansonic	004	037	041	045	066	067	071	084	184	211
Aolinpiya	178									
Aolinpu	251									

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
Apollo	088									
Arc en Ciel	192	203	287	305						
Arcam	061	244								
Arcam Delta	179									
Aristona	004	041	059							
Arthur Martin	083	204								
ASA	042	047	076	098	115	132	177	185	186	187
	257	299								
Asberg	004	043	059							
Astra	037									
Asuka	015	061	069	178	179					
Atlantic	004	059	061	067	074	084	179			
Atori	037									
Auchan	083									
Audiosonic	004	015	037	059	061	075	084	137	179	203
	211									
AudioTon	061	179	211							
Ausind	043									
Autovox	043	061	066	080	084	115	177	178	179	274
	304									
Awa	039	061	077							
Ayomi	063									
Baihehua	248									
Baihua	178	247								
Baile	246	247								
Baird	061	077	100	114	137	196	203	218	220	289
Bang & Olufsen	115	177								
BaoHuaShi	178									
Baosheng	245	247								
Barco	322									
BARON	004	112								
Basic Line	004	015	037	059	061	069				
Bastide	061	179								
Bauer	046									
Baur	001	004	046	080	187	197	202			
Bazin	061									
Beijing	037	178	245	246	247	248				
Beko	004	016	017	020	181	194	211	325		
Benq	158									
Beon	004	060	085							

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
Best	075	211								
Bestar	004	059	211	216						
Bestavision	004	152								
Binatone	061	179								
Black Star	066	201								
Blacktron	069									
Blackway	069									
Blaupunkt	004	046	183	303						
Blue Sky	004	015	069	086	092					
Blue Star	069									
Bondstec	066	201								
Boots	060	061	179	189	300					
BPL	004	069	113	114	116	118	119			
Brandt	021	022	101	137	192	203	224	261	286	287
	305									
Brinkmann	004	085								
Brionvega	004	059	115	177						
Britannia	061	179	244							
Bruns	115	177	181							
BSR	073	187								
BTC	015									
Bush	004	015	016	025	031	037	051	055	059	061
	064	069	073	080	092	093	104	111	112	120
	159	187	188	189	191	202	203	216	239	258
	263	267	300	312	318					
Caihong	245	247								
Cailing	131									
Caixing	248									
Capsonic	178									
Carena	004	086								
Carrefour	042	055	064							
Cascade	004	037								
Casio	160									
Cathay	004	059								
CCE	061									
Centurion	004	059								
Century	066	115	177	275						
CGE	043	066	085	187	201	211	275			
Chang Cheng	037	178	243	245	246	247	248			
Changfei	245	247	253							

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
Changfeng	178	245								
Changhai	245	247	253							
Changhong	006	037	245	247						
Chaparral	230									
Chengdu	245									
Chimei	001									
Chunfeng	178	247								
Chunlan	093									
Chunsun	245	247								
Cimline	015	037	258							
City	037									
Clarivox	004	260								
Clatronic	004	015	031	037	043	045	059	061	066	074
	085	111	178	179	190	194	201	211	275	325
CMS	061									
CMS Hightec	061									
Concorde	037									
Condor	004	037	045	059	061	066	069	074	084	179
	194	211	295	315	325					
Conrowa	178	247								
Contec	037	039	055	061	064	179	190	244		
Continental Edison	025	137	192	196	203	224	261	286	287	305
Cosmel	037	075								
Crosley	043	066	115	177	187	191	201	275		
Crown	004	037	043	056	059	085	155	191	194	198
	211	325								
Crystal	191									
CS Electronics	015	061	066	179	201	244				
CTC	066	201	275							
CTC Clatronic	184									
Cybertron	015									
Daewoo	004	015	036	037	059	061	156	179	216	244
Dainichi	015	061	244							
Dansai	004	006	059	060	061	178	244			
Dantax	004	017	086	211						
Datsura	198									
Dawa	004									
Daytron	037									
Dayu	246									
De Graaf	072	114	187	191						

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
Decca	004	059	061	077	100	179	189	190	200	272
	277	300								
Denver	093	161								
Desmet	004	059	074							
Diamant	004									
Diamond	061									
Dixi	004	037	059	061						
DongBao	037									
DongDa	037	247								
Donghai	247									
DongHua	037									
DTS	037									
Dual	004	061	067	080	081	179	187	203	205	283
	304	305								
Dual-Tec	037	061	067	179	187					
Dumont	042	045	061	098	115	132	177	179	184	186
	257									
Dux	004									
Dynatron	004	059								
Elbe	004	015	061	063	067	071	084	091	200	211
	260	297								
Elbe-Sharp	200									
Elcit	045	066	177	200						
	069									
ELECTRO TECH	037									
Elektra	069									
Elin	004	037	047	059	061	080	132	179	185	191
	257									
Elite	004	015	059	315						
Elman	045	184	187							
Elta	037	061								
Emerson	004	031	042	057	066	098	101	115	177	187
	211	275								
Emperor	069									
Epson	096	097								
Erres	004	040	041	059						
ESC	061									
Etron	037									
Eurofeel	061	178								
Euroline	004									

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
Euroman	004	059	061	069	178	179	211			
Europhon	004	045	059	061	066	179	184	187	189	200
Expert	067	083	084							
Exquisit	004									
Feilang	247									
Feilu	245	247								
Feiyan	178									
Feiyue	245	247	248							
Fenner	037	216								
Ferguson	004	021	022	044	063	087	101	137	196	218
	220	259	260	262	266	286	289			
Fidelity	004	031	061	179	187	191	195	200	244	273
	320									
Filmnet	225									
Filsai	061									
Finlandia	076	114	187	191	299					
Finlux	004	042	043	045	047	059	061	076	084	098
	100	115	132	177	179	184	185	186	187	200
	207	257	263	265	268	299				
Firstline	004	037	045	059	061	063	066	073	080	084
	092	100	179	201	216	244	258	267	275	
Fisher	038	055	061	064	080	100	114	132	177	179
	187	194	211	257	325					
Flint	004	015	059	086	100					
FNR	045									
Formenti	004	009	043	061	074	115	177	179	187	244
	304	315								
Formenti-Phoenix	004	061								
Fortress	009	177								
Fraba	004	211								
France Telecom	235									
Friac	211									
Frontech	031	037	061	066	080	111	178	187	191	197
	201	275								
Fujitsu	045	061	084	100						
Fujitsu General	061									
Funai	073	111	178	207						
FUTEC	121									
Galaxi	004	045	085	194						
Galaxis	004	045	085	211						

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
Ganxin	245	248								
GBC	015	037	055	077	187					
Geant Casino	083									
GEC	004	034	059	061	077	080	100	179	187	200
	202									
Geloso	037	066	187							
General	087									
General Technic	037									
Genexxa	004	015	059	187	191	321				
Giant	061									
GoldHand	061									
Goldline	004									
GoldStar	004	037	059	060	061	066	082	137	179	187
	191	201	209	211	256	275	293	319		
Goodmans	004	006	025	031	037	046	051	053	055	059
	060	061	064	093	100	101	102	111	159	162
	163	164	172	176	178	196	200	207	209	216
	254	255	258	285	289	293	324			
Gorenje	194	211	325							
GPM	015									
Graetz	187	191	202							
Granada	004	038	041	043	054	055	059	061	062	064
	072	080	083	088	100	101	114	179	187	191
	200	229	264							
Grandin	004	015	037	069						
Gronic	061									
Grundig	004	025	042	043	046	093	098	122	123	183
	186	211	274	306						
Haier	004	124	252							
HaiHong	037									
Haiyan	178	245	248							
Halhong	247									
Halifax	061	178	179							
Hampton	061	179								
Hanseatic	004	037	055	059	061	069	071	073	074	080
	179	181	187	197	211	270	315	323		
Hantarex	004	037	200							
Hantor	004									
Harwood	004	037	060	285	321					
Hauppauge	004									

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
HCM	004	015	037	061	069	085	178	179	273	321
Hema	037	061								
Hemmermann	080									
Hifivox	203									
Higashi	061									
HiLine	004									
Hinari	004	015	025	037	043	055	059	064	114	207
	258	307	318							
Hisawa	015	069	083	086						
Hisense	072									
Hitachi	002	003	004	034	036	047	048	049	052	055
	060	061	064	072	080	088	100	128	137	167
	179	185	187	191	192	197	200	202	203	222
	224	261								
Hitch Fufian	072	178	245	248						
Hongmei	178	245	247	248						
Hongyan	178	245								
Hornyphon	004	059								
Hoshai	015	086								
Hotel TV	187									
Huafa	247									
Huanghaimei	247									
Huanghe	245	247	248							
Huanglong	247									
Huangshan	178	245	247	248						
Huanyu	061	072	178	179	216	244	245	248		
Huaqiang	178									
Huari	178									
Huodateji	243									
Hygashi	061	179								
Hyper	037	061	066	179	187	201				
Hypson	004	059	061	069	083	086	111	178	179	
Hyundai	126									
Iberia	004									
ICE	004	015	031	037	059	061	111	178	179	
ICeS	015	061								
Imperial	004	043	059	066	080	085	187	194	201	211
	275	325								
Imperial Cown	178	246								
Indesit	188	274								

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
<i>Indiana</i>	004	059								
<i>Ingelen</i>	187	191								
<i>Ingersol</i>	037									
<i>Inno Hit</i>	004	015	037	043	059	061	066	077	100	179
	200	209	293							
<i>Innovation</i>	004	005	031	037	051	151	178	196	215	216
	233	265								
<i>INTER</i>	237									
<i>Interactive</i>	211									
<i>Interbuy</i>	037	066	201	298						
<i>Interfunk</i>	004	041	059	068	177	187	191	201	203	211
	275									
<i>International</i>	061									
<i>Intervision</i>	004	015	045	061	066	069	082	086	111	178
	179	184	211	298						
<i>Irradio</i>	004	015	031	037	043	059	066	209		
<i>Isukai</i>	004	015	069							
<i>IT</i>	236									
<i>ITC</i>	061	179	187							
<i>ITS</i>	004	015	031	059	061	069				
<i>ITT</i>	037	076	080	088	114	187	191	202	207	265
	308	324								
<i>ITT Nokia</i>	314									
<i>ITV</i>	004	037	066							
<i>JEC</i>	006									
<i>Jiahua</i>	243									
<i>JiaLiCai</i>	037	178	247							
<i>Jinfeng</i>	243	245								
<i>Jinque</i>	178	245	247							
<i>Jinta</i>	178	247	248							
<i>Jinxing</i>	178	245								
<i>Juhua</i>	178	245	248							
<i>JVC</i>	015	031	055	059	064	070	166	218	220	
<i>Kaige</i>	178	245	247	248						
<i>Kaisui</i>	004	015	037	061	069	086	179	244		
<i>Kamosonic</i>	179									
<i>Kamp</i>	061	179								
<i>Kangli</i>	178	245	246	247	248					
<i>Kangyi</i>	178	247								
<i>KanLi</i>	037									

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
KanYi	110									
Kapsch	067	084	132	187	191					
Karcher	004	037	045	069	091	179	185	211	260	
Kathrein	004									
Kawasho	061									
Kendo	004	045	066	084	091	184	187	211	258	297
Kennedy	084	187								
KIC	061									
Kingsley	061	084	179	244						
Kneissel	004	063	067	071	084	091	211			
Kolster	004	059								
Kongque	178	245	247	248						
Konka	015	058	085	127						
Korpel	004	059								
Korting	074	115	177	211						
Kosmos	004									
Koyoda	037									
KTV	061	179								
Kuaile	178	247								
Kunlun	178	243	245	246						
Kuro	198									
Kyoto	061	260								
Lasat	211									
Lenco	037	132								
Lenoir	037	179								
Lesla	066	201								
Leyco	004	059	073	077	100	111	155	178		
LG	004	007	008	016	037	059	061	066	082	128
	157	179	187	201	209	211	256	293		
LG/GoldStar	004									
Liesenk	004									
Liesenkotter	004									
Life	004	005	031	037	051	151	178	196	215	216
	233	265								
Lifetec	004	005	015	031	037	051	092	151	178	196
	215	216	233	265						
Lihua	245									
Lloyds	037									
Loewe	004	071	115	200	208	211				
Loewe Opta	004	059	177							

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
Logik	039	168	190							
Longjiang	178	245								
Luma	004	037	067	084	187	191				
Lumatron	004	059	061	067	084	187	273			
Lux May	059									
Luxor	061	080	089	179	187	191	202	209	222	274
	278	293	324							
Magnadyne	004	045	066	115	177	184	187	200	201	275
Magnafon	043	045	061	179	184	200				
Magnum	004	005	031	037	051	151	178	196	215	216
	233	265								
Mandor	178									
Manesth	004	006	059	061	073	074	111	178	179	258
	315									
Marantz	004	059								
Marelli	115	177								
Mark	004	037	059	061						
Masuda	061									
Matsui	001	004	006	025	031	037	038	039	046	055
	057	059	061	064	070	073	080	086	100	101
	114	120	155	169	179	187	189	190	191	193
	200	239	258	267	300	318				
Matsushita	005									
McMichael	034									
Mediator	004	040	041	059						
Medion	004	005	031	037	051	092	151	178	196	215
	216	233	265							
Meile	178	245	248							
MeiShi	110									
MElectronic	004	031	037	047	059	061	066	076	084	089
	132	137	179	185	187	191	203	216	257	286
	298	299	324							
Melvox	083									
Memorex	037									
Memphis	037	075	100	317						
Mengmei	248									
Mercury	004	037								
Metz	004	046	065	068	115	151	177	183	276	309
	310									
Micromaxx	004	005	031	037	051	151	178	196	215	216

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
	233	265								
Microstar	004	005	031	037	051	151	178	196	215	216
	233	265								
Minerva	025	042	043	046	098	183	186	200	274	
Minoka	004	059	191	321						
Mitsubishi	004	026	029	035	039	046	054	055	059	064
	115	177	183	190	264	274				
Mivar	043	061	071	090	179	200	209	210	211	244
	270	293								
MoDeng	110									
Motion	043									
MTC	004	061	080	191	202	211				
MuDan	111	178	243	245	247					
Multistandard	045									
Multisystem	004									
Multitech	004	037	043	045	055	061	066	080	179	184
	187	191	192	201	211	244				
Murphy	061	100	132	179	187	257				
NAD	187									
Naiko	004									
Nanbao	178	247								
Nansheng	178	245								
Naonis	187	297								
National	062	242	274							
NEC	024	055	056	061	064	074				
Neckermann	001	004	046	059	061	066	080	084	085	115
	177	179	183	187	191	194	197	202	211	
NEI	004	031	059	075	191	317				
Nesco	066	201	207							
Network	075									
Neufunk	004	037								
New Tech	004	037	059	061						
New World	015									
Nicamagic	061	179								
Nikkai	004	006	015	037	059	060	061	064	075	100
	111	178	179	244	317					
Nobliko	042	043	045	061	179	184	186			
Nogamatic	203									
Nokia	076	080	088	089	114	187	191	202	265	268
	278	308	314	324	329					

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
Nordic	061									
Nordmende	046	059	101	137	177	187	188	192	196	203
	224	261	286	289	305					
Nordvision	004									
Normende	286									
Novatronic	004	047								
Oceanic	073	083	187	191	202					
Okano	004	100	194	211						
ONCEAS	179									
Onida	004	059	129	130						
Onwa	015	193								
Opera	004									
Orbit	004	059								
Orion	004	016	037	039	045	051	053	057	059	073
	074	120	190	200	202	258	267	276	315	318
Orline	004	015								
Ormond	004									
Orsowe	200									
Osaki	001	004	015	060	061	100	111	178	179	216
	273	285	300	321						
Oscar	116									
Osio	209									
Oso	015									
Osume	004	015	055	060	064	100				
Otake	060									
Other Brand	249									
Others	227									
Otto Versand	001	004	009	046	055	059	061	062	064	066
	069	073	074	080	179	183	187	191	196	197
	198	200	202	203	258	289	315			
Pael	061	179								
Palladium	001	004	061	066	080	084	085	179	191	194
	211	256	325							
Palsonic	061									
Panama	001	004	037	061	066	111	178	179		
Panasonic	004	005	011	033	062	175	187	191	200	202
	242	274	290	302	309	310				
Panavision	004	084								
Panda	178	243	245	247	248					
Pathe Cinema	061	063	071	074	080	083	179	187	191	211

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
	224	244	260	266	270	315				
<i>Pathe Marconi</i>	192	203	260	261	287	305				
<i>Pausa</i>	037									
<i>Pensonic</i>	131									
<i>Perdio</i>	004	061	074	100	191	315				
<i>Perfekt</i>	004									
<i>Philco</i>	004	043	066	085	115	177	187	201	211	275
<i>Philharmonic</i>	001	061	179							
<i>Philips</i>	004	012	013	014	019	030	034	040	041	043
	046	059	093	115	125	133	134	173	174	177
	179	187	196	216	283	294	311	316		
<i>Phoenix</i>	004	059	061	074	100	115	177	211	315	
<i>Phonola</i>	004	040	041	059	061	115	177			
<i>Pilot</i>	002	060	093	238	240	241				
<i>Pioneer</i>	004	056	059	137	182	187	191	203	211	286
<i>Plantron</i>	004	037	059	178						
<i>Playsonic</i>	061									
<i>Polaroid</i>	095									
<i>Polestar</i>	228									
<i>Poppy</i>	037									
<i>Prandoni Prince</i>	043	066	187	200						
<i>Praxis</i>	231									
<i>Precision</i>	001	061	179							
<i>Prima</i>	037	187								
<i>Prinz</i>	080	100	222							
<i>Profex</i>	037	043	187	191						
<i>Profilo</i>	004									
<i>Profi-Tronic</i>	004	045	059							
<i>Proline</i>	004	021	040	041	100	267				
<i>Promac</i>	131	135								
<i>Prosonic</i>	004	016	017	061	151	155	179	211	242	
<i>Protech</i>	001	004	037	059	061	075	085	111	178	179
	184	187	191	201	202	275	317			
<i>Provision</i>	004									
<i>Pye</i>	004	031	040	041	059					
<i>Pymi</i>	037									
<i>Qingdao</i>	178	243	245							
<i>Quandra Vision</i>	083									
<i>Quasar</i>	201									
<i>Quelie</i>	201									

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
Quelle	001	004	039	042	046	047	055	059	061	064
	066	073	080	098	132	178	179	183	185	186
	187	190	201	209	257					
Questa	055	060	064							
Radialva	004	015								
Radiola	004	040	041	059	061	316				
Radiomarelli	004	066	115	177	200	201	229			
RADIONETTE	185	257								
RadioShack	004									
Radiotone	004	037	059	085	155	181	211			
Rank	042	055	064	186						
RBM	098	186								
RCA	114									
Recor	004									
Rediffusion	187	229								
Redstar	004									
Reflex	004									
Revox	004	059	211							
Rex	066	067	084	111	178	187	191	297		
RFT	071	100	115	177	181	200	211	323		
Rhapsody	061									
R-Line	004	059								
Roadstar	015	037	051	085	111	136	178			
Robotron	177									
Rowa	061									
Royal Lux	211									
RTF	177									
Ruyi	072	245	248							
Saba	021	022	101	115	137	156	177	187	191	192
	196	200	202	203	224	261	286	289	305	
saccs	260									
Sagem	086	091								
Saige	245	247								
Saikou	285									
Saisho	037	039	057	061	111	178	179	190	191	200
	239	258								
Salora	080	114	138	139	151	187	191	197	198	200
	202	209	222	293	297					
Sambers	043	045	184	200						
Samsung	001	004	037	059	061	077	078	079	093	100

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
	111	140	141	178	179	190	194	205	209	211
	293	296	301	325	326					
Sandra	061	179	244							
Sanjian	178									
Sansui	004	006	059	086	108	110	131	142	143	
Sanyo	015	018	037	038	039	043	055	061	064	071
	077	100	101	114	132	179	185	187	190	205
	211	257	270							
Sanyuan	245	247	248							
Saville	051									
SBR	004	034	040	041						
Schaub Lorenz	080	187	202							
Schneider	004	015	031	040	041	059	061	066	067	080
	081	092	151	179	187	203	205	269	275	304
	316									
SEG	004	037	043	054	055	061	064	066	092	111
	178	179	184	187	201					
SEI	001	004	045	057	073	080	115	200		
SEI-Sinudyne	001	057	073	177	184	187	200	276		
Seleco	055	067	084	187	191	297				
Sencora	037									
Sentra	006	015	037							
Serino	061	086	091							
Shancha	178	245								
Shangguangdian	049									
Shanghai	178	245	247	248	253					
Shaofeng	072	245	248							
Sharp	004	009	012	019	023	055	059	064	073	144
	145	200								
Shencai	178	247								
ShengCai	037									
Shengli	059									
Shenyang	178	245	247							
Sherwood	247									
Shorai	073	207								
Siarem	004	045	046	055	115	177	184	187	191	200
Sicatel	260									
Siemens	004	046	055	064	183					
Sierra	004	041	059							
Siesta	205	211								

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
Silva	061									
Silver	055	064	207							
Singer	045	066	083	115	177	184	187	201		
Sinudyne	001	004	045	057	073	080	115	177	184	187
	200	258	276							
Skantic	080	187	191							
Skyworth	121	178	245							
Sogera	074									
Solavox	060	100	187	191	292					
Solovox	191									
Songbai	247									
SongRi	037									
Sonitron	061	114	211							
Sonoko	004	037	059	061	069	178	179			
Sonolor	001	083	114	187	191					
Sontec	004	059	073	205	211					
Sony	001	037	039	045	055	064	094	099	100	101
	146	165	170	190						
Sound & Vision	015	045	184							
Soundwave	004	059	074	085						
Standard	001	004	015	037	059	061	074	179		
Starlite	004	037								
Stenway	015	069								
Stern	067	084	187	191						
Strato	004	037								
Stylandia	061									
Sunkai	015	037	073	086	258	267	318			
Sunstar	004	037								
Sunwood	004	037	059							
Superla	061	179	200							
SuperTech	004	037	061	197						
Supra	037									
Susumu	015	101								
Sutron	037									
SYC LINE	004									
Sydney	001	061	179							
Sylvania	199									
Sysline	004									
Sytong	061									
Tai Wah	004									

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
Taishan	245	247								
TALENT	046									
Tandberg	073	075	084							
Tandy	001	009	015	061	066	100	179	187	191	
Tantec	189									
Tashiko	001	034	055	056	060	061	064	179	187	191
	244	285								
Tatung	001	004	039	051	059	061	077	100	173	179
	189	200	272	277	300					
TCL	110	147	250							
TCM	004	005	016	024	031	037	051	085	101	121
	151	159	172	178	196	206	212	214	215	216
	217	219	221	223	233	265				
Teac	004	061	086							
Tec	001	037	061	066	075	087	101	179	187	201
	275									
Technema	074	315								
Technics	005									
Technovision	234									
TEDELEX	061									
Teleavia	137	192	196	203	286	287	289	305		
Telecor	004	015	061	067						
Telefunken	004	021	022	059	087	101	137	196	203	259
	262	274	280	281	284	286	288	289	297	305
Telegazi	004	015	067							
Telemeister	004	074	315							
TELESERVICE	226									
Telesonic	004									
Telestar	004									
Teletech	004	037	066	075	201					
Teleton	001	061	064	067	068	080	084	179	197	202
Televideon	061	074								
Televiso	083									
Telewest	330									
Temco	073									
Tensai	004	015	037	047	059	060	061	066	073	074
	082	132	257	315						
Tenson	074									
Tesmet	059									
Tevion	004	005	031	037	051	151	178	196	215	216

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
	233	265								
Texet	001	015	037	061	179	216	244			
Texla	112									
Thomson	004	021	022	024	044	059	087	101	116	137
	156	179	180	191	192	196	203	213	224	261
	262	274	279	286	287	289	291	305		
Thorn	001	004	006	046	063	077	100	101	132	187
	196	216	218	220	257	259	260	264	289	327
Thorn-Ferguson	111									
Tiane	245									
TOBO	178	247								
Tokai	004	059	061	075	100					
Tokyo	006	061	179							
Tomashi	069									
Tongguang	178									
Toshiba	006	016	027	028	032	042	045	046	051	055
	061	064	098	117	140	148	149	150	154	171
	183	186	232	271						
Towada	045	061	080	187						
Trakton	061									
Trans Continens	004	061								
Transtec	061									
Trident	001	061	200							
Tristar	015									
Triumph	004	057	076	200	271					
Uher	004	043	059	067	074	084	085	187	211	315
Ultra	220									
Ultravox	004	045	061	066	115	177	179	184	187	201
Unic Line	004	088								
Union	006									
United	004									
Universum	001	004	039	042	043	046	047	055	057	059
	061	064	066	073	075	076	080	084	085	088
	089	111	132	178	185	187	194	201	209	211
	257	279	299	314	324	325	329			
Vegavox	085									
Vestel	004	059	061	075	187	194	201	215	292	
Vexa	004	037								
Victor	005	055	059							
Videocon	004	006	037	106	108	111	119	142	152	153

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
VIDEOLOGIC	061									
Videologique	015	061	179							
Videosat	201									
VideoSystem	004	059								
Videotechnic	061	074								
Videoton	080	191								
Viewsonic	069	103								
Visiola	061	179								
Vision	004	059	061	074	315					
Visorex	195									
Vistar	187									
Vortec	004	059								
Voxson	004	043	059	085	115	177	187	191	297	
Waltham	001	004	061	080	085	179	187	191	260	
Warumaia	246									
Watson	004	015	059	074	155	315				
Watt Radio	045	061	080	179	184	187	260			
Wega	004	055	064	115	177					
Wega Color	055									
Wegavox	037									
Weipai	247									
Weltblick	004	059	061	074						
Weston	187									
Wharfedale	004									
White Westinghouse	004	043	061	074	075	179	184	244	315	
Windstar	069									
Xiahua	178	245	247							
Xiangyang	178									
Xiangyu	247									
Xihu	178	245	248							
Xinaghai	178	247								
Xingfu	247									
Xinsida	253									
Xrypton	004									
Xuelian	248									
Yamaha	002									
Yamishi	004	015	061	069	086					
YingGe	037	247	248							
Yokan	004									
Yoko	001	004	015	037	059	061	111	178	179	191

Remote control tuning codes (These codes are accurate as of January 2009)

BRAND NAME	SET UP CODE									
	211									
<i>Yonggu</i>	247	248								
<i>Yorx</i>	015									
<i>Youlanasi</i>	245	248								
<i>Yousida</i>	247									
<i>Yuhang</i>	247									
<i>Zanussi</i>	061	084	187	191	297					
<i>Zenith</i>	226									
<i>Zhuhai</i>	247									